




by MAXONIX®

Drum Key Clips

~ Stop losing your drum keys ~



Universal fit adhesive back clip instantly turns any smooth surface into a convenient storage location for your drum keys.

Great for drum kit players, drum corps and marching band drummers too.

- **Quick**
- **Easy to apply**
- **Fit 99% of drum keys**
- **Secure** (holds drum keys tight, even upside-down)

Ideal for flat & smooth surfaces. Also works on surfaces with light textures such as common black powder coated music gear, cases, etc. Works on some surfaces with gradual curve, such as large diameter drum cases.

Works great on drum shells – ! caution, sticks on strong, so be sure where you want it before you put it on!



Add to our Zero-G™ drumstick holder.

Attach to:

- drumstick holder
- Hi-Hat stand legs
- cymbal stand legs
- drum hoop/rim
- drum lugs (some styles)
- throne underside
- throne legs
- drum shell
- inside drum case tops
- kick pedal apparatus
- drum cases
- trap cases
- drum machines
- monitor/speaker cabs
- flat ends of rack tubes
- drum pad housings
- trigger housings

... & much more

GigTrix™ Drum Key Holder Clips hold a wide variety of drum key types



Image Copyright © 2009 by Maxonix®
Note: drum keys not included with clips,
keys shown here to illustrate usage only.
Maxonix® & its GigTrix™ product line are
not associated with Tama®, Pearl®, Gretsch®, or Premier®.

www.maxonix.com

email: sales@maxonix.com • phone: (813) 932-3499

Copyright © 2009 by Maxonix® – part of our GigTrix™ product line

#MX-DKHC2-02G



by MAXONIX®